

Instructions For Use

• English

UNIVERSAL A/C REMOTE CONTROL

Default Function

Our product is available for: GREE (YBOF2), Mitsubishi 388, Midea, Toshiba Chunlan, Haier, HuaLing etc. If it's not working, please try to operate it with one of the methods below:

Setting Of The Remote Control

A> Brand point to point fast searching

1. Switch on the power of the air condition manually, align the remote control with the receiving window of the air condition.
2. Long press the CODE button until the air condition begins to automatically run with a voice of tick, and then release the button, and the setup is finished.

Button Brand Corresponding Table

ON/OFF	TEMP+	TEMP-	WIND
GREE/ HAIER	MIDEA/ TOSHIBA/ CHANGHONG	SHARP/ KELON	mitsubishi/ OTHERS
MODE	M.SWING	A.SWING	TIME ON
LG/SAMSUNG/ MI/SKYWORTH	HITACHI/ PAMASONIG	SANYO/ HISENSE	CHIGO/ DAIKIN
TIME OFF	F.Cool FAST COOLING	F.Heat FAST HEATING	
FUJITSU/ CARRIER	CHUNLAN/ AUX	SHINGO/ AUCMA	

B> Digital auto searching for the available type

1. Switch on the power of the air condition manually, align the remote control with the receiving window of the air condition.
2. Press and hold the "SET" button for 6 seconds until the type code has changed (+1), now it's in the mode of fast searching for the available type. Checking the status of your air condition and press "OK" button to finish the searching when the air condition starts automatically
3. Check the function of the buttons whether working or not (except the TEMP+, TEMP-, TIME ON, TIME OFF, SET buttons). Press the "OK" button to finish if there is no problem and the code is effective, if not, press "SET" button to keep on searching.

C> Input the code manually

1. Switch on the power of the air condition manually, find out the type of your air condition and the first code from the code table. Take HAIER as an example.
2. Press and hold the "SET" button for about 3 seconds until the type code is flickering in the window, then press "TEMP+" button until the code you need is on the window and flickering, the air condition will start up if the code is right.
3. Press "OK" button and then the code of the type will stop flickering.
4. Check the function of the buttons on the remote control to make sure there is no problem. The setup is finished if there is no problem. If not, repeat the step 2-3.

D> Searching the code manually

1. Switch on the power of the air condition manually, align the remote control with the receiving window of the air condition.
2. Press and hold the "SET" button for about 3 seconds until the type code is flickering in the window, then press "TEMP+" button one time. Checking the status of your air condition and press "OK" button to finish the searching when the air condition starts automatically.

Restore to factory settings

Press the "SET" + "WIND" button at the same time and hold about 3 seconds to restore to factory settings.

Some of the remote control have the functions below (refer to the panel of the remote control)

1. FAST COOLING, FAST HEATING button

The air condition will be set to the heating mode by pressing the "FAST COOL" button, the temperature is 21°C, strong wind, automatic direction.

The air condition will be set to the heating mode by pressing the "FAST HEAT" button, the temperature is 27°C, strong wind, automatic direction.

* In the mode of heating, press the "E A Heating" button to start the electrical heating function. This function is suitable for some models.

2. Set the CLOCK function

Press the "CLOCK" button (about 3 seconds) to get in the mode of clock setting and then the clock is flickering, adjust the time by pressing the "TEMP+" button and the "TEMP-" button. Press the "CLOCK" button again to exit.

3. TIME ON/OFF function

Equipped with the original remote control timing function, the timing indicator light of the air condition will light up after pressing the "TIME ON" or "TIME OFF" button, and it means that the air condition is working in the timing status.

Note:

The combination code has no timing function when it is switched on, please find the appropriate type according to the set-method (one of the A B C D) in the Instruction Manual.

*The TIME ON function of some types is only available in the shutdown mode.

CODE

2082 v2

ACSON	980	LIANGYU	780-789
AIRWELL	926	LIKEAIR	386-387
AITE	296-299	LILYTECH	918
AKIRA	796-797	LITTLESWAN	453,913,927
ALPIN	989-991,998	LONGHE	861
AMCOR	501,508,509,532,973, 978,979	LOREN-SEBO	801-803
AMICO	982	MCQUAY	790-795
AOKE	301-302	MEILING	388-391
AOLI	300	MIDEA	040-058
APTON	862	MINGXING	290
AUCMA	210-229,941	mitsubishi	551-599,827,972
AUX	180-199	MITSUKA	904
BAIXUE	299	NATIONAL	660-689,902,970
BEIJINGJINGDIAN	304,820,967	NEC	500-550,860,943,946
BEKO	882	NIKKO	810-811
BIG-THUMB	331	NISO	398-399,497
BLUE STAR	057,550,887	NISO	497
BOERKA	305-306,630	NORCA	994
BOERKA	630	NOTRIZ	858,923
BORLER	307	OLIMPIA SPLENDID	824
BOSHI	310	OLYMPUS	995-996
BOSHIGAO	308-309	OPAL	997
BOYIN	290	PANASONIC	660-689,902,970
CAIXING	311	PANDA	464-466
CARRIER	599,690-699,890-899	PEREG	998
CASARTE	908	PILOT	902
CHANGFENG	190	PINSHANG	290
CHANGFU	835-838,874,907	PUYI	862
CHANGHONG	059-079,942,947	QIXING	393
CHANGLING	312-323	RASONIC	970
CHENGYUAN	324	RAYBO	371-383
CHIGO	080-099,245	RESTPOINT	090
CHUANGHUA	325-328	RHOSS	903
CHUANYAN	861	RICAI	394
CHUNLAN	170-179	RIJIANG	395-397
COLROLLA	861	ROWA	383-385
COMBINE	994	SABRO	161,197,240
CONROWA	337-341	SACON	414
CONSUL	993	SAJODENKI	390,812,813,816
CORONA	760-769	SAMSUNG	610-629
CROWN	861	SANYO	500-550,840-841,869-871,873,876, 823,916,920,924,959,860,943,946
DAEWO	332-333	SANZUAN	190
DAIKIN	740-759	SAPORO	861
DAJINXING	329-330	SASAKI	820,911,912
DAKE	861	SAST	450-452
DAOTIAN	822-823	SENSOR	860
DELONGHI	469,822,900,960,968, 984	SERENE	499
DIY	044,090,092,095	SHAMEI	400
DONGXIA	334-335	SHANGLING	403-409
DONGXINBAO	260-268	SHANXING	401-402
DONGYANGHUIFENG	357,360	SHANYE	862
DUNAN	336	SHARP	249,720-739,917
ELBA	439	SHENBAO	410-411
ELCO	982	SHENGFENG	412
ELDLONG	293-295,861	SHENGFENG	413
ELECTER	981-986	SHINCO	200-209
ELECTROLUX	250,471-474,807,808, 906	SHINING	415
FEDDERS	878,938,939,964	SHUANGLU	416-418,946,948
FEIEDRICH	879	SIGMA	447
FEIGE	829-830,821	SKYWORTH	877
FEILU	240-249,413	SOGO	291
FERROLIT	901	SONGGE	226,868,925
FIRST	864	SONGLINXIA	862
FRESTECH	270-279,944,945	SONGXING	419
FUJITSU	257,700-719,966,950	SOVA	292
FUNAI	246,248,258,267	SOVA	292,420
FUNIKI	992	SOYA	862-863
GALANZ	124-129,134-149,936 ~940	SOYEA	421-422
GEER	342-343	SPEED	987
GENERAL	288	SRTC	423
GLEE	280	STARIGHT-AIRCON	880
GOLDSTAR	303	SUMMER	859,910
GOODWEATHER	827	SUNBURG	817-820
GREE	000,020-039	SUNDRUNG	260,268,804
GUANGDA	345-346	TADAIR	501,508,509,532,630,969,978,
GUANYUAN	997	TAIYA	979,991
GUQIAO	344	TATUNG	862
HAIER	001-019	TCL	158,242,243
HELTON	863	TEAC	120-139
HEMILTON	095	TECO	850-859,139
HICON	391-392	TECO	831-834
HISENSE	230-239	TIANJINKONGTIAO	015
HITACHI	640-659	TIANYUAN	424
HONGYI	347	TOBO	425-428
HUABAO	100-109	TONGLI	250-269,915
HUAGAO	348	TOSHIBA	429-430
HUAKE	349-350	TOTALINE	630-639
HUALING	150-169,045	TOYO	548
HUAMEI	351-352	TRANE	825-828
HUANGHE	353	TRANE	812-816,922
HUAWEI	281	UNI-AIR	922
HUIFENG	354-356	UTTLEDUCK	368-369
HYUNDAI	780-789	VIDEOCON	454-456,909
INYCIN	475-483,826	VOLTAS	597,627,628,629,884
JDC	227,244,653	WANBAO	056,057,549,598,609,627,628, 629
JIALE	358	WANGZI	431-433
JIANGNAN	359	WEILI	861
JINBEIJING	361-362	WEITELI	434-443,553-576
JINDA	491-492	WHIRLPOOL	444
JINSONG	363-365	WUFENG	119,550,770-774,739,828
JMSTAR	360	XILENG	445-446
JOHNSON	282	XINGHE	448-449
JUHUA	969	XINHUBAO	462-463
KANGLI	368-370	XINLING	290
KELONG	110-119,914	XINLING	457-460
KLIMATAIR	797,798,799,800	XIONGDI	461
KONKA	366-367	YAIR	862
KRIS	804	YOMA	013-015,044,467-471
KT02-D001	283	YIDONG	470,977,738
KT02-D002	284	YONGXIN	499
KTY001	285	YORK	918
KTY002	286	YUETU	775-779
KTY003	287	YUTU	881-882,949
KTY004	288	ZHONGYI	484-490
KTY005	289	ZUODAN	493-494
LEADER	921,971,973,994	OGENERAL	495
LG	600-609	OTHER	659,717,718,719 496,498,821-828,839-849,865 ~876,905-976,999